


4. Sequence Test

- Components: -
1. Sequence Meter
 2. Necessary incoming phases



Connect the brown, black and gray phases regularly at distribution board incoming point to the sequence meter.

Note: - Rotation must be done clock direction

Preview from Notesale.co.uk
Page 3 of 3