## Direct Addressing Mode • In this mode, the address of the preview and is given in the instruction itself.

## LDA 2500 H Load the contents of memory location 2500 H in accumulator.

- LDA is the operation.
- 2500 H is the address of source.
- Accumulator is the destination.